

Highway Congestion PM Peak Travel Time Indices 2012, Chicago Region

Prepared September, 2014 by CMAP for
the Illinois Dept. of Transportation

Sources:
HERE,
Midwest Software Solutions (MS2),
IDOT, CMAP

Scale: 1:135,000
Illinois State Plane West
NAD 83

Legend

- Travel Time Index
- <= 1.10: Little Congestion
 - to 1.25: Light Congestion
 - to 1.50: Moderate Congestion
 - to 1.75: Heavy Congestion
 - to 2.00: Very Heavy Congestion
 - > 2.00: Extreme Congestion



The PM peak travel time index is the ratio of average travel time during the PM peak (4 PM to 7 PM on weekdays) to the free-flow travel time (measured from 8 PM to 5:30 AM). The travel time index is a measure of highway congestion.

